































































Original		Replacement		Original		Replacement	
	Power		Power		Vol+		Vol +
	HDMI1		1		Vol-		Vol -
	HDMI2		2		Mute		Mute
	HDMI ARC		3		Voice		Media
	Coax		Red		Music		Menu
	Optical		Green		Movie		Info
	Audio In		Yellow		Rear Vol-		4
	AUX		Blue		Rear Vol+		5
	Bluetooth		Smart		Audio Sync-		7
	I<		I<<		Audio Sync+		8
	Play		Play		Night		Options
	Pause		Pause		Auto Vol		Dual
	>I		>>I		DIM		Subt
	Bass+		Up		Calibration		TV/R
	Bass-		Down				
	Treble+		Ch +				
	Treble-		Ch -				

