



















































































| Original  | Replacement |   |                       |
|---|-------------|---|-----------------------|
|    | Power       |    | Power                 |
|    | Ambilight   |    | D.Menu / Top          |
|    | Sources     |    | AV / Input / RDS      |
|    | Settings    |    | Setup / OPT /         |
|    | Top Picks   |    | Picture / Format      |
|    | Search      |    | TV/Radio /            |
|    | Exit/TV     |    | Exit / Cancel / Clear |
|    | Tv Guide    |    | Guide / EPG / -/--    |
|    | Windows     |    | Display / Media       |
|   | List        |   | Smart / List          |
|  | Up          |  | Up                    |
|  | Left        |  | Left                  |
|  | OK          |  | OK                    |
|  | Right       |  | Right                 |
|  | Down        |  | Down                  |
|  | ←           |  | Back / Return         |
|  | +           |  | Info / Angle          |

| Original  | Replacement |   |                             |
|---|-------------|---|-----------------------------|
|    | Home        |    | Menu / Home                 |
|    | Red         |    | Red / Netflix / Search      |
|    | Green       |    | Green / APP / Repeat        |
|    | Yellow      |    | Yellow / YouTube / Repeat   |
|    | Blue        |    | Blue / Prime Video / Random |
|    | Vol+        |    | Vol+                        |
|    | Netflix     |    | Shift + Red / Netflix /     |
|    | CH+         |    | CH+ / Page+                 |
|    | Vol-        |    | Vol-                        |
|   | Mute        |   | Mute / Dimmer               |
|  | CH-         |  | CH- / Page-                 |
|  | 1           |  | 1                           |
|  | 2           |  | 2                           |
|  | 3           |  | 3                           |
|  | 4           |  | 4                           |
|  | 5           |  | 5                           |
|  | 6           |  | 6                           |





| Original  |          | Replacement   |                       | Original |  | Replacement |  |
|---|----------|---|-----------------------|----------|--|-------------|--|
|    | 7        |    | 7                     |          |  |             |  |
|    | 8        |    | 8                     |          |  |             |  |
|    | 9        |    | 9                     |          |  |             |  |
|    | Subtitle |    | Subtitle / EQ         |          |  |             |  |
|    | 0        |    | 0                     |          |  |             |  |
|    | Text     |    | Text / Goto           |          |  |             |  |
|    | Stop     |    | Stop / Hold           |          |  |             |  |
|    | Pause    |    | Pause / Step / Freeze |          |  |             |  |
|    | Rec      |    | Rec / Rec Mode        |          |  |             |  |
|    | <<       |    | << / Tune-            |          |  |             |  |
|   | Play     |   | Play / Slow           |          |  |             |  |
|  | >>       |  | >> / Tune+            |          |  |             |  |
|   |          |   |                       |          |  |             |  |
|   |          |   |                       |          |  |             |  |
|   |          |   |                       |          |  |             |  |
|   |          |   |                       |          |  |             |  |
|   |          |   |                       |          |  |             |  |
|   |          |   |                       |          |  |             |  |
|   |          |   |                       |          |  |             |  |
|   |          |   |                       |          |  |             |  |

