













	Original	Replacement		Original	Replacement
	Power		Power		
AUX	AUX		7		
COAX	COAX		2		
AUDIO-IN	Audio In		Audio / Lang I/II		
OPTICAL	Optical		Zoom / Size		
	Bass+		Up		
	Vol+		Vol+		
	Treble+		CH+ / Page+		
	Bass-		Down		
	Vol-		Vol-		
	Treble-		CH- / Page-		
	Mute		Mute / Dimmer		
SURR	SURR		TV/Radio /		

