


































Original	Replacement	Original	Replacement
	Power		Green / APP / Repeat
	Home		Yellow / YouTube / Repeat
	Guide		Blue / Prime Video / Random
	UP		1
	I<		2
	OK		3
	Right		4
	Down		5
	Back		6
	Option		7
	III		8
	Vol+		9
	Mute		Subtitle / EQ
	Vol-		0
	Red		Picture / Format
	Red / Netflix / Search		

