





































































































Original	Replacement	Original	Replacement
 Power	 Power	 Pr+	 Ch +
 1	 1	 Pr-	 Ch -
 2	 2	 Vol+	 Vol +
 3	 3	 Vol-	 Vol -
 4	 4	 Mute	 Mute
 5	 5	 Source	 AV
 6	 6	 Return	 Shift + Back
 7	 7	 Home	 Menu
 8	 8	 Up	 Up
 9	 9	 Down	 Down
 0	 0	 Right	 Right
 PC	 Pre Ch	 Left	 Left
 [i+]	 Info	 Enter	 Ok
 [II]	 Options	 Exit	 Exit
 [<>]	 3D	 EPG	 Guide
 Back	 Back	 Red/Rec	 Red
 Tv/DTV	 TV/R	 Green/Pause	 Green









































































Original		Replacement		Original	Replacement
	Yellow/Stop		Yellow		
	Blue/Play		Blue		
	[...]		Subt		
	[≡?]		Eject		
	[≡i]		List		
	Text		Text		
	HDMI Control		Smart		
	I-II		Dual		
	[> <]		Sleep		
	Size [<>]		Format		
	Input 1		Shift + 1		
	Input 2		Shift + 2		
	Input 3		Shift + 3		
	Input 4		Shift + 4		
	Input 5		Shift + 5		





Original	Replacement	Original	Replacement
 Power	 Power	 Down	 Down
 1	 1	 Right	 Right
 2	 2	 Left	 Left
 3	 3	 Enter	 Ok
 4	 4	 Menu	 Menu
 5	 5	 DVD Top	 D. Menu
 6	 6	 Return	 Back
 7	 7	 Play	 Play
 8	 8	 Stop	 Stop
 9	 9	 Pause	 Pause
 0	 0	 >>	 >>
 PC	 Pre Ch	 <<	 <<
 Source	 AV	 >>	 >>
 Mute	 Mute	 <<	 <<
 Vol +	 Vol +	 HDMI Control	 Smart
 Vol -	 Vol -	 Input 1	 Shift + 1
 Up	 Up	 Input 2	 Shift + 2







































































Original	Replacement	Original	Replacement
3 Input 3	 + 3 Shift + 3		
4 Input 4	 + 4 Shift + 4		
INPUT 5 Input 5	 + 5 Shift + 5		

































































Original		Replacement		Original		Replacement	
	Power		Power		PR+		Ch +
	Source		AV		PR-		Ch -
	1		1		Menu		Menu
	2		2		Exit		Exit
	3		3		DVD Top Menu		D. Menu
	4		4		HDMI Control		Smart
	5		5		Up		Up
	6		6		Down		Down
	7		7		Right		Right
	8		8		Left		Left
	9		9		Enter		Ok
	0		0		Input 1		Shift + 1
	PC		Pre Ch		Input 2		Shift + 2
	[i+]		Info		Input 3		Shift + 3
	Mute		Mute		Input 4		Shift + 4
	Vol +		Vol +		Input 5		Shift + 5
	Vol -		Vol -				





Original	Replacement	Original	Replacement
	Power		Power
	Source		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	PC		Pre Ch
	Vol+		Vol +
	Vol-		Vol -
	PR+		Ch +
	PR-		Ch -
	Mute		Mute
	Play		Play
	Stop		Stop
	Pause		Pause
	Rec		Rec
	>>		>>
	<<		<<
	HDMI Control		Smart
	Input 1		Shift + 1
	Input 2		Shift + 2
	Input 3		Shift + 3
	Input 4		Shift + 4
	Input 5		Shift + 5

