










































































































Original	Replacement	Original	Replacement
 Standby	 Power	 Menu	 Menu
 Mute	 Mute	 Exit	 Exit
 ATV	 Smart	 Up	 Up
 Tv/Radio	 TV/R	 Down	 Down
 Tv Guide	 Guide	 Right	 Right
 USB	 Media	 Left	 Left
 Rec	 Rec	 OK	 Ok
 I<<	 I<<	 1	 1
 >>I	 >>I	 2	 2
 Stop	 Stop	 3	 3
 <<	 <<	 4	 4
 >>	 >>	 5	 5
 Play	 Play	 6	 6
 Pause	 Pause	 7	 7
 Rec List	 List	 8	 8
 AV/Source	 AV	 9	 9
 i/Info	 Info	 0	 0





Original	Replacement
 Back	 Back
 FAV	 Pre Ch
 Vol+	 Vol +
 Vol-	 Vol -
 Subtitle	 Subt
 Aspect	 3D
 Audio	 Dual
 Sleep	 Sleep
 CH+	 Ch +
 CH-	 Ch -
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Text	 Text
 Index	 Options
 Reveal	 D. Menu

Original	Replacement
 Power/Display	 Shift + Power
 P.Mode	 Shift + Format
 Size	 Format
 Hold/Lang	 Shift + Dual
 S.Mode	 Eject

