












| Original | Replacement | Original | Replacement |
|---|---|---|--|
|  Power |  Power |  PR + |  Up |
|  Mute |  Mute |  PR - |  Ch - |
|  1 |  1 |  PR - |  Down |
|  2 |  2 |  Vol + |  Vol + |
|  3 |  3 |  Vol + |  Right |
|  4 |  4 |  Vol - |  Vol - |
|  5 |  5 |  Vol - |  Left |
|  6 |  6 |  OK |  Ok |
|  7 |  7 |  SWAP |  Back |
|  8 |  8 |  16:9 |  Format |
|  9 |  9 |  White / i |  Info |
|  0 |  0 |  Red |  Red |
|  --/-- |  GUIDE |  Green |  Green |
|  AV / TV |  TV/R |  Yellow |  Yellow |
|  Menu |  Menu |  Blue |  Blue |
|  TXT |  Text |  Stop |  Stop |
|  PR + |  Ch + |  Reveal |  Smart |

| Original | Replacement | Original | Replacement |
|---|--|---|--|
|  PR + |  Up |  TV |  AUX |
|  PR - |  Ch - |  DVD |  SAT |
|  PR - |  Down |  SLEEP |  REC MODE |
|  Vol + |  Vol + |  PLAY MODE |  STOP |
|  Vol + |  Right |  PAUSE |  EJECT |
|  Vol - |  Vol - |  SKIP BACKWARD |  SKIP FORWARD |
|  Vol - |  Left |  DISC NAV |  SOUND |
|  OK |  Ok |  AD |  SETTINGS |
|  SWAP |  Back |  LIST |  SUBT |
|  16:9 |  Format |  DUAL |  OPT |
|  White / i |  Info |  SEARCH |  PICTURE |
|  Red |  Red |  SLEEP |  FORMAT |
|  Green |  Green |  TV/R |  3D |
|  Yellow |  Yellow |  E-MANUAL |  TIMER |
|  Blue |  Blue |  REPEAT |  ZOOM |
|  Stop |  Stop |  TEXT |  AV |
|  Reveal |  Smart |  TOP MENU |  DISPLAY INFO |





| | Original | Replacement | | Original | Replacement |
|---|----------|--|--|----------|-------------|
|  | Double |  Media | | | |
|  | SUB |  Subt | | | |
|  | MIX |  +  Shift + Text | | | |
|  | Update |  Eject | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

