




| Original | Replacement | Original | Replacement |
|--|---|---|---|
|  Power |  Power |  OK |  OK |
|  [=]/Text |  Text / Goto |  Right |  Right |
|  I-II |  Audio / Lang I/II |  Down |  Down |
|  [<>]/[+] |  Shift + Picture / Format |  A/D |  Shift + Audio / Lang I/II |
|  AV/[?] |  AV / Input / RDS |  EPG |  Guide / EPG / -/- |
|  Red |  Red / Netflix / Search |  Vol+ |  Vol+ |
|  Green |  Green / APP / Repeat |  Mute |  Mute / Dimmer |
|  Yellow |  Yellow / YouTube / Repeat |  PR+ |  CH+ / Page+ |
|  Blue |  Blue / Prime Video / Random |  Vol- |  Vol- |
|  [...] |  Subtitle / EQ |  PR- |  CH- / Page- |
|  [1 2] Split Window |  Display / Media |  1 |  1 |
|  Cancel |  Exit / Cancel / Clear |  2 |  2 |
|  Option |  Setup / OPT / |  3 |  3 |
|  Tv Menu |  Menu / Home |  4 |  4 |
|  Digital Menu |  D.Menu / Top |  5 |  5 |
|  Up |  Up |  6 |  6 |
|  Left |  Left |  7 |  7 |





| | Original | Replacement | | Original | Replacement |
|--|---|-------------------|--|------------------|-------------|
| | | 8 | | 8 | |
| | | 9 | | 9 | |
| |  | [i+] | | Info / Angle | |
| | | 0 | | 0 | |
| | | P<P/Back | | Back / Return | |
| | | [-O-]/Active Ctrl | | Smart / List | |
| | | DV3/Tv/Radio | | TV/Radio / | |
| | | Sound Smart | | Sound / Title | |
| | | Picture Smart | | Picture / Format | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

