




















































	Original	Replacement		Original	Replacement
	Power		Power		CH List
	Source		AV		List
	1		1		Ch +
	2		2		Ch -
	3		3		Content
	4		4		Menu
	5		5		Tools
	6		6		Guide
	7		7		Info
	8		8		Return
	9		9		Exit
	0		0		Up
	--		Smart		Down
	PRE-CH		Pre Ch		Right
	Vol+		Vol +		Left
	Vol-		Vol -		Enter
	Mute		Mute		Red
					Green





Original		Replacement		Original	Replacement
	Yellow		Yellow		
	Blue		Blue		
	E-Manual		D. Menu		
	SRS		Dual		
	P.Mode		3D		
	P.Size		Format		
	CC		Subt		
	MTS		Text		
	<<		<<		
	I<<		I<<		
	Pause		Pause		
	>>		>>		
	>>I		>>I		
	Rec		Rec		
	Play		Play		
	Stop		Stop		

