



	Original	Replacement		Original	Replacement
	Power		Power		Ch.List
	Source		AV		List
	1		1		Ch +
	2		2		Ch -
	3		3		Media.P
	4		4		Media
	5		5		Menu
	6		6		Menu
	7		7		Guide
	8		8		Options
	9		9		Up
	0		0		Right
	TTX/MIX		Text		Down
	PRE-CH		Pre Ch		Left
	Vol+		Vol +		Ok
	Vol-		Vol -		Back
	Mute		Mute		Exit
					Red
					Green





Original		Replacement		Original	Replacement
	Yellow		Yellow		
	Blue		Blue		
	P.Mode	 + 	Shift + Format		
	Dual I/II		Dual		
	3D		3D		
	AD	 + 	Shift + Subt		
	P.Size		Format		
	Subt.		Subt		
	<<		<<		
	Pause		Pause		
	>>		>>		
	Rec		Rec		
	Play		Play		
	Stop		Stop		

