






















































Original	Replacement
 DVD	 Shift + 2
 VCR	 Shift + 4
 Input Sel.	 AV / Input / RDS
 Standby / On	 Power
 Open / Close	 Eject / Surround
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Angle	 Shift + Info / Angle
 0	 0
 Audio	 Audio / Lang I/II

Original	Replacement
 I<<	 I<< / Preset-
 F.ADV / Skip	 Fav / Marker / PC
 Pause	 Pause / Step / Freeze
 >>I	 >>I / Preset+
 <<	 << / Tune-
 Stop	 Stop / Hold
 Play	 Play / Slow
 >>	 >> / Tune+
 PROG/TRK +	 CH+ / Page+
 PROG/TRK -	 CH- / Page-
 Menu	 Menu / Home
 Up	 Up
 Return	 Back / Return
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down





































Original	Replacement
 Title List / Disc Menu	 D.Menu / Top
 Info	 Info / Angle
 Playlist / Title Menu	 Smart / List
 Anykey	 Yellow / YouTube / Repeat
 Subtitle	 Subtitle / EQ
 TV / VCR	 Display / Media
 REC	 Rec / Rec Mode
 Rec Speed	 Setup / OPT /
 Cancel	 Exit / Cancel / Clear
 Timer Rec	 Sleep / Timer
 Copy To DVD	 Red / Netflix / Search
 Copy To VCR	 Green / APP / Repeat

Original	Replacement





Original	Replacement	Original	Replacement
 TV Standby/On	 Power		
 1	 1		
 2	 2		
 3	 3		
 4	 4		
 5	 5		
 6	 6		
 7	 7		
 8	 8		
 9	 9		
 0	 0		
 Vol+	 Vol+		
 TV Mute	 Mute / Dimmer		
 Prog. +	 CH+ / Page+		
 Vol-	 Vol-		
 Prog. -	 CH- / Page-		

