






































| Original   | Replacement  |
|--|--|
|  Power  |  Power          |
|  P.Mode |  Shift + Format |
|  S.Mode |  Shift + Dual   |
|  I/II   |  Dual           |
|  Sleep  |  Sleep          |
|  1      |  1              |
|  2      |  2              |
|  3      |  3              |
|  4      |  4              |
|  5      |  5              |
|  6     |  6             |
|  7    |  7            |
|  8    |  8            |
|  9    |  9            |
|  0    |  0            |
|  10+  |  Guide        |
|  Back |  Back         |

| Original   | Replacement  |
|--|--|
|  Source           |  AV     |
|  Menu             |  Menu   |
|  Info             |  Info   |
|  Exit             |  Exit   |
|  Up               |  Up     |
|  Down             |  Down   |
|  Right            |  Right  |
|  Left             |  Left   |
|  OK               |  Ok     |
|  Vol+             |  Vol +  |
|  Vol-            |  Vol - |
|  Mute           |  Mute |
|  Aspect         |  3D   |
|  CH+            |  Ch + |
|  CH-            |  Ch - |
|  Play/Pause/EPG |  Play |
|  Stop/FAV       |  Stop |





| Original  |                  | Replacement   |         | Original | Replacement |
|---|------------------|---|---------|----------|-------------|
|    | Eject/Add/Del    |    | Pre Ch  |          |             |
|    | Media            |    | Media   |          |             |
|    | [.≡]/I<</TTX     |    | Text    |          |             |
|    | [≡x]/<</Cancel   |    | TV/R    |          |             |
|    | [≡◆]/Title/Size  |    | Format  |          |             |
|    | Subtitle         |    | Subt    |          |             |
|    | [≡+]/>>/Hold     |    | Options |          |             |
|    | [≡?]/>>/Reveal   |    | Eject   |          |             |
|    | [≡o]/Menu/Subpa  |    | D. Menu |          |             |
|   | [≡i]/Audio/Index |   | List    |          |             |
|  | Red/Goto         |  | Red     |          |             |
|  | Green/Slow       |  | Green   |          |             |
|  | Yellow/Repeat    |  | Yellow  |          |             |
|  | Blue/A-B         |  | Blue    |          |             |
|  | DVD Setup        |  | Smart   |          |             |
|   |                  |   |         |          |             |
|   |                  |   |         |          |             |

