






































































| Original | Replacement | Original | Replacement |
|--|---|--|--|
|  Power |  Power |  Yellow / FAV |  Pre Ch |
|  Mute |  Mute |  Blue / SLP |  Blue |
|  Up / CH+ |  Up |  Zoom |  Eject |
|  Up / CH+ |  Ch + |  Freeze |  Pause |
|  Left / Vol- |  Left |  Blue / SLP |  Sleep |
|  Left / Vol- |  Vol - |  DSP / CAPS |  Info |
|  Right / Vol+ |  Right |  Recall |  Back |
|  Right / Vol+ |  Vol + |  1 |  1 |
|  Down / CH- |  Ch - |  2 |  2 |
|  Down / CH- |  Down |  3 |  3 |
|  Enter |  Ok |  4 |  4 |
|  Menu |  Menu |  5 |  5 |
|  Red / P.M |  Red |  6 |  6 |
|  Red / P.M |  Format |  7 |  7 |
|  Green / S.M |  Green |  8 |  8 |
|  Green / S.M |  Shift + Dual |  9 |  9 |
|  Yellow / FAV |  Yellow |  0 |  0 |



