



Original		Replacement		Original		Replacement	
	Standby		Power		Menu		Menu
	Mute		Mute		EPG		Guide
	1		1		Exit		Exit
	2		2		CH+		Ch +
	3		3		CH-		Ch -
	4		4		Up		Up
	5		5		Down		Down
	6		6		Right		Right
	7		7		Left		Left
	8		8		OK		Ok
	9		9		Vol+		Vol +
	0		0		Vol-		Vol -
	FAV		Pre Ch		Text		Text
	Audio		Dual		Red		Red
	Recall		Back		Green		Green
	Subtitle		Subt		Yellow		Yellow
	Info		Info		Blue		Blue





	Original	Replacement	Original	Replacement
 REC LIST	Rec List	 LIST		List
 TV/RADIO	Tv/Radio	 SEARCH TV/R		TV/R
 STOP	Stop	 		Stop
 PAUSE	Pause	 		Pause
 REV	<<	 		<<
 FWD	>>	 		>>
 RECORD	Record	 REC MODE		Rec

