





Original	Replacement
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Menu	 Menu
 TV / AV	 AV
 Red / I/II	 Red
 Red / I/II	 Dual
 Left / Vol-	 Vol -

Original	Replacement
 Green / Sleep	 Green
 Green / Sleep	 Sleep
 Yellow / Q.View	 Yellow
 Blue / List	 Blue
 Blue / List	 List
 Up / PR+	 Up
 Up / PR+	 Ch +
 Down / PR-	 Down
 Down / PR-	 Ch -
 Right / Vol+	 Right
 Right / Vol+	 Vol +
 Left / Vol-	 Left
 OK	 Ok
 PSM	 Format
 SSM	 Shift + Dual
 PC/*	 Smart
 ARC/*	 Media





Original	Replacement	Original	Replacement
Text	Text		
Size	Eject		
Hold	Stop		
Index	Info		
Update	Play		
Time	Shift + AV		
Reveal	Pause		
Mix	Shift + Text		

Original	Replacement

