



| Original | Replacement | Original | Replacement |
|----------|-------------|----------|-----------------------|
| | Input | | AV / Input / RDS |
| | Power | | Power |
| | [▼] | | Fav / Marker / PC |
| | Text | | Text / Goto |
| | Subtitle | | Subtitle / EQ |
| | O)/I/II | | Audio / Lang I/II |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | AD | | Sound / Title |
| | 0 | | 0 |
| | ATV/DTV | | TV/Radio / |
| | Vol+ | | Vol+ |
| | [≡i]/[i+] | | Info / Angle |
| | PR+ | | CH+ / Page+ |
| | Vol- | | Vol- |
| | Mute | | Mute / Dimmer |
| | PR- | | CH- / Page- |
| | Quick | | Smart / List |
| | Guide | | Guide / EPG / -/- |
| | Up | | Up |
| | Exit | | Exit / Cancel / Clear |
| | Left | | Left |
| | OK | | OK |
| | Right | | Right |
| | Menu | | Menu / Home |
| | Down | | Down |
| | Return | | Back / Return |





| Original | | Replacement | | Original | | Replacement | |
|---|------------|---|-----------------------------|----------|--|-------------|--|
|  | Red |  | Red / Netflix / Search | | | | |
|  | Green |  | Green / APP / Repeat | | | | |
|  | Yellow |  | Yellow / YouTube / Repeat | | | | |
|  | Blue |  | Blue / Prime Video / Random | | | | |
|  | [≡?] |  | Display / Media | | | | |
|  | [≡+] |  | Stop / Hold | | | | |
|  | [≡◆] |  | Zoom / Size | | | | |
|  | Timer/[≡x] |  | Sleep / Timer | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

