























































	Original	Replacement		Original	Replacement
	Standby		Power		Search
	Menu		Menu		TV/R
	Title		Options		Stop
	Setup		Sleep		Pause
	Up		Up		Repeat
	Down		Down		Text
	Right		Right		Shift + Eject
	Left		Left		Eject
	>>		>>		Shift + Play
	<<		<<		Vol +
	>>		>>		Vol -
	<<		<<		1
	Subtitle		Subt		2
	Angle		Guide		3
	Audio		Dual		4
	Play		Play		5
	Display		Info		6
					7
					8



