















































































Original	Replacement
 Power	 Shift + Power
 Open/Close	 Eject / Surround
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Clear	 Exit / Cancel / Clear
 0	 0
 Mute	 Mute / Dimmer
 Sub-T	 Subtitle / EQ
 On/Off	 Power
 Audio	 Audio / Lang I/II

Original	Replacement
 A-B	 Yellow / YouTube / Repeat
 Zoom	 Zoom / Size
 Camera/Digest	 Text / Goto
 Title/PBC	 Shift + Sound / Title
 Menu/RTN	 Menu / Home
 I<</Prev/AF	 I<< / Preset-
 >>I/Next/Text	 >>I / Preset+
 <</FR/SR	 << / Tune-
 >>/FF/SF	 >> / Tune+
 Play/Pause/Eon	 Play / Slow
 Stop/PTY	 Stop / Hold
 >I</Step	 Pause / Step / Freeze
 Setup	 Setup / OPT /
 Up	 Up
 Left	 Left
 Sel	 OK
 Right	 Right





Original	Replacement
	 Down
	 Vol-
	 Vol+
	 Shift + I<< / Preset-
	 Shift + >>I / Preset+
	 Fav / Marker / PC
	 Display / Media
	 Shift + Eject / Surround
	 Shift + 3
	 Blue / Prime Video / Random
	 Green / APP / Repeat
	 AV / Input / RDS
	 Shift + 6
	 TV/Radio /
	 Sound / Title
	 Picture / Format
	 Shift + Audio / Lang I/II

Original	Replacement
	 Sleep / Timer
	 Smart / List
	 Shift + << /
	 Shift + >> /

