
















































| Original | Replacement |
|---|--|
|  Power |  Power |
|  Display |  Display / Media |
|  Eject |  Eject / Surround |
|  CH+ |  CH+ / Page+ |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  CH- |  CH- / Page- |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  Vol+ |  Vol+ |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  Vol- |  Vol- |
|  0 |  0 |

| Original | Replacement |
|--|--|
|  Clear |  Exit / Cancel / Clear |
|  Subtitle |  Subtitle / EQ |
|  Return |  Back / Return |
|  NTSC/PAL |  Picture / Format |
|  Program |  TV/Radio / |
|  Setup |  Setup / OPT / |
|  Edit |  Text / Goto |
|  Title |  Sound / Title |
|  Menu/PBC |  Menu / Home |
|  Red/Record |  Red / Netflix / Search |
|  Red/Record |  Rec / Rec Mode |
|  Green/TV/DVD |  Shift + 2 |
|  Green/TV/DVD |  Green / APP / Repeat |
|  Green/TV/DVD |  Shift + 1 |
|  Up |  Up |
|  Left |  Left |
|  Enter |  OK |





| Original | Replacement |
|---|---|
|  Right |  Right |
|  Yellow/Source |  Yellow / YouTube / Repeat |
|  Yellow/Source |  AV / Input / RDS |
|  Down |  Down |
|  Blue/HDD/DVD |  Shift + 7 |
|  Blue/HDD/DVD |  Blue / Prime Video / Random |
|  Play |  Play / Slow |
|  Pause |  Pause / Step / Freeze |
|  > |  Shift + Pause / Step / |
|  Stop |  Stop / Hold |
|  I<< |  I<< / Preset- |
|  >>I |  >>I / Preset+ |
|  << |  << / Tune- |
|  >> |  >> / Tune+ |
|  Zoom |  Zoom / Size |
|  1/All |  Shift + Green / APP / |
|  A/B |  Shift + Yellow / YouTube / Repeat |

| Original | Replacement |
|---|--|
|  Slow |  Shift + Play / |
|  Random |  Shift + Blue / Prime |
|  CM Skip |  Guide / EPG / -/-- |
|  Bookmark |  Fav / Marker / PC |
|  Quality |  D.Menu / Top |
|  TimeShift |  Sleep / Timer |
|  Angle |  Info / Angle |
|  Audio |  Audio / Lang I/II |
|  Mute |  Mute / Dimmer |

