





































Original	Sustituto
 Power	 Power
 Sleep	 Sleep / Timer
 Mute	 Mute / Dimmer
 Source	 AV / Input / RDS
 1	 1
 2	 2
 3	 3
 Audio/Lang	 Audio / Lang I/II
 4	 4
 5	 5
 6	 6
 Tv/Radio	 TV/Radio /
 7	 7
 8	 8
 9	 9
 Exit	 Exit / Cancel / Clear
 CH.List	 Smart / List

Original	Sustituto
 0	 0
 Back	 Back / Return
 Menu	 Menu / Home
 CH-	 CH- / Page-
 Up	 Up
 CH+	 CH+ / Page+
 Left	 Left
 Enter	 OK
 Right	 Right
 Vol-	 Vol-
 Down	 Down
 Vol+	 Vol+
 Setup	 Setup / OPT /
 Play/Timeshift	 Play / Slow
 Pause	 Pause / Step / Freeze
 Stop	 Stop / Hold
 Eject	 Eject / Surround





Original		Sustituto		Original		Sustituto	
	Rec		Rec / Rec Mode		Yellow/A-B		Yellow / YouTube / Repeat
	Text		Text / Goto		Blue/Repeat		Blue / Prime Video / Random
	<<		<< / Tune-				
	>>/Reveal		>> / Tune+				
	I<</Hold		I<< / Preset-				
	>>I/Sub.P		>>I / Preset+				
	SUB.T		Subtitle / EQ				
	Index/Title		Shift + Sound / Title				
	Size/Zoom		Zoom / Size				
	D.Menu		D.Menu / Top				
	EPG		Guide / EPG / -/--				
	FAV/Prog		Fav / Marker / PC				
	P.Mode/Lang		Picture / Format				
	S.Mode/Search		Sound / Title				
	Info/Display		Info / Angle				
	Red/Angle		Red / Netflix / Search				
	Green/Slow		Green / APP / Repeat				

