







































































Original	Sustituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Audio	 Dual
 Recall	 Back
 Tv-Menu	 Menu
 Source	 AV
 CH.List	 List

Original	Sustituto
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 Sound	 Shift + Dual
 PIC	 Options
 CH+	 Ch +
 CH-	 Ch -
 Sleep	 Sleep
 Aspect	 3D
 Freeze	 Shift + Media
 Tv/Radio	 TV/R
 Text	 Text





Original	Sustituto
 EPG	 Guide
 FAV	 Pre Ch
 Info	 Info
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Reveal	 Eject
 Hold	 D. Menu
 List	 Smart
 Index	 Shift + Info
 Subpage	 Shift + Subt
 Size	 Format
 MIX	 Media
 Subtitle	 Subt
 <<	 <<
 >>	 >>

Original	Sustituto
 <<	 <<
 >>	 >>
 Play	 Play
 Pause	 Pause
 Stop	 Stop
 Rec/Rep	 Rec

