



Original	Sustituto
CALL	Info / Angle
[≡]/[≡]/[]	Text / Goto
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Recall	Back / Return
0	0
Source/[≡o]	AV / Input / RDS
→ / ←	Picture / Format
→ J ←	Sound / Title

Original	Sustituto
Menu	Menu / Home
Exit	Exit / Cancel / Clear
P+	CH+ / Page+
Up	Up
Left	Left
Vol-	Vol-
OK	OK
Vol+	Vol+
Right	Right
P-	CH- / Page-
Down	Down
Red	Red / Netflix / Search
Blue	Blue / Prime Video / Random
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
O) /	Audio / Lang I/II
[<>]	Shift + Picture / Format





Original	Sustituto	Original	Sustituto
Mute	Mute / Dimmer		
Backlight	Smart / List		
[≡?]	D.Menu / Top		
[≡+]	Stop / Hold		
[≡◆]	Zoom / Size		
[O]/[≡x]	Setup / OPT /		

