







































































| Original | Sustituto |
|--|--|
|  Power |  Power |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  Q.View |  Sound / Title |
|  Home |  Menu / Home |
|  Q.Menu |  D.Menu / Top |
|  Guide |  Guide / EPG / -/-- |
|  List |  Smart / List |
|  Mute |  Mute / Dimmer |

| Original | Sustituto |
|---|--|
|  Input |  AV / Input / RDS |
|  Tv/Rad |  TV/Radio / |
|  AV Mode |  Shift + AV / Input / RDS |
|  Energy/Saving |  Eject / Surround |
|  Portal |  Display / Media |
|  Vol+ |  Vol+ |
|  Vol- |  Vol- |
|  P+ |  CH+ / Page+ |
|  P- |  CH- / Page- |
|  Info |  Info / Angle |
|  Exit |  Exit / Cancel / Clear |
|  Back |  Back / Return |
|  OK |  OK |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |





| Original | Sustituto | Original | Sustituto |
|---|-----------|---|-----------------------------|
|  | Red |  | Red / Netflix / Search |
|  | Green |  | Green / APP / Repeat |
|  | Yellow |  | Yellow / YouTube / Repeat |
|  | Blue |  | Blue / Prime Video / Random |
|  | Text |  | Text / Goto |
|  | Subtitle |  | Subtitle / EQ |
|  | AD |  | Audio / Lang I/II |
|  | Play |  | Play / Slow |
|  | T.Opt |  | Setup / OPT / |
|  | Alarm |  | Sleep / Timer |
|  | Stop |  | Stop / Hold |
|  | Pause |  | Pause / Step / Freeze |
|  | Simplink |  | Zoom / Size |
|  | << |  | << / Tune- |
|  | >> |  | >> / Tune+ |
|  | Ratio |  | Picture / Format |
|  | Mark |  | Fav / Marker / PC |

