



Original	Sustituto
SOURCE	AV / Input / RDS
	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
EPG	Guide / EPG / -/--
0	0
PRE-CH	Back / Return
HDMI	Shift + 0
YPbPr	Setup / OPT /
Video	Shift + 4

Original	Sustituto
PC	Shift + Fav / Marker / PC
CH+	CH+ / Page+
	Mute / Dimmer
Vol+	Vol+
Vol-	Vol-
Zoom	Zoom / Size
CH-	CH- / Page-
Dual	Audio / Lang I/II
ADJ Audio	Sound / Title
ADJ Video	Picture / Format
Sleep	Sleep / Timer
	Up
	Left
	OK
	Right
	Menu / Home
	Exit / Cancel / Clear





Original	Sustituto		
	Down		Down
	Info		Info / Angle
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Teletext		Text / Goto
	Mix		Shift + Text /
	Size		Shift + Zoom /
	Subpage		>> / Tune+
	Index		Play / Slow
	Subtitle		Subtitle / EQ
	Hold		Stop / Hold
	Reveal		<< / Tune-
	FAV		Fav / Marker / PC
	CH-List		Smart / List
	AD		Shift + Audio / Lang I/II

Original	Sustituto		
	Freeze		Pause / Step / Freeze

