



Original	Sustituto	Original	Sustituto
 Power	 Power	 8	 8
 Open / Close	 Eject	 9	 9
 TV / DTV	 TV/R	 +/-	 Shift + Guide
 Line	 AV	 0	 0
 DVD	 Media	 PRE	 Pre Ch
 TTX	 Text	 Vol +	 Vol +
 PIP ON / OFF	 Shift + Power	 Vol -	 Vol -
 PIP Swap	 Shift + Back	 Prog +	 Ch +
 PIP Source	 Shift + AV	 Prog -	 Ch -
 PIP Sound	 Shift + Dual	 M/S	 Subt
 1	 1	 Still	 Shift + Pause
 2	 2	 Sleep	 Sleep
 3	 3	 TV Menu	 Menu
 4	 4	 P.STD	 Format
 5	 5	 S.STD	 Shift + Subt
 6	 6	 P.Size	 Shift + Format
 7	 7	 Exit / Cancel	 Exit





Original	Sustituto
	
Up	Up
	
Right	Right
	
Down	Down
	
Left	Left
	
Enter	Ok
	
Mute	Mute
	
Display	Shift + Info
	
Stop	Stop
	
Play	Play
	
Pause	Pause
	
<<	<<
	
>>	>>
	
I<<	I<<
	
>>I	>>I
	
Red / Setup	Red
	
Green / Title	Green
	
Yellow / Menu	Yellow

Original	Sustituto
	
Blue	Blue
	
Index Repeat	Shift + Text
	
MIX A-B	Shift + TV/R
	
L/F Audio	Dual
	
Size Subtitle	3D
	
Reveal Goto	Back
	
Hold / Program / Menu	Shift + Menu
	
Prepage / Angle / List	List
	
Next Page / Surround / Opt	Options
	
Subpage / Zoom / EPG	Guide
	
Store / Clear / i	Shift + Exit
	
Store / Clear / i	Info

