












































































































Original	Sustituto	Original	Sustituto
 Power	 Power	 Pause	 Pause
 Input	 AV	 I<<	 I<<
 Function	 D. Menu	 <<	 <<
 Sleep	 Sleep	 >>	 >>
 Title	 List	 >>I	 >>I
 Display	 Info	 Tv-HT SPK	 Smart
 Menu	 Menu	 Vol+	 Vol +
 Up	 Up	 Vol-	 Vol -
 Setup	 Options	 Mute	 Mute
 Down	 Down	 EQ	 Dual
 Right/Tun+	 Right	 VSM	 Format
 Left/Tun-	 Left	 Repeat	 Text
 Enter	 Ok	 Subtitle	 Subt
 Return	 Back	 1	 1
 REC	 Rec	 2	 2
 Stop	 Stop	 3	 3
 Play	 Play	 4	 4





Original	Sustituto
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Prog.Memo	 +  Shift + Sleep
 Clear	 EXIT Exit
 RDS	 3D
 PTY	 Pre Ch
 TV Power	 +  Shift + Power
 TV Prog-	 Ch -
 TV Prog+	 Ch +
 TV Input	 +  Shift + AV
 TV Vol+	 +  Shift + Vol +
 TV Vol-	 +  Shift + Vol -

Original	Sustituto

