







































































Original	Sustituto	Original	Sustituto
 Power	 Power	 [...]	 Subt
 Input	 AV	 Red	 Red
 Digital/Analog	 D. Menu	 Green	 Green
 Audio	 Dual	 Yellow	 Yellow
 [+]	 3D	 Blue	 Blue
 Sync Menu	 Menu	 Guide	 Guide
 1	 1	 [i]/[?]	 Info
 2	 2	 Return	 Back
 3	 3	 Options	 Options
 4	 4	 Up	 Up
 5	 5	 Down	 Down
 6	 6	 Right	 Right
 7	 7	 Left	 Left
 8	 8	 OK	 Ok
 9	 9	 Home	 Smart
 0	 0	 Vol+	 Vol +
 [=]/Text	 Text	 Vol-	 Vol -





	Original	Sustituto	Original	Sustituto
	Mute	 Mute		
	Prog+	 Ch +		
	Prog-	 Ch -		
	Recall	 Pre Ch		
	<<	 <<		
	Play	 Play		
	>>	 >>		
	Rec	 Rec		
	Pause	 Pause		
	Stop	 Stop		
	Title List	 List		

