



Original	Sustituto	Original	Sustituto
Power	Power	P+	Ch +
Source	AV	P-	Ch -
1	1	CH List	List
2	2	Smart Hub	Smart
3	3	Menu	Menu
4	4	Search	TV/R
5	5	Tools	Options
6	6	Info	Info
7	7	Return	Back
8	8	Exit	Exit
9	9	Up	Up
0	0	Down	Down
TTX/MIX	Text	Right	Right
PRE-CH	Pre Ch	Left	Left
Vol+	Vol +	Enter	Ok
Vol-	Vol -	Red	Red
Mute	Mute	Green	Green

Original	Sustituto	Original	Sustituto
Power	Power	P+	Ch +
Source	AV	P-	Ch -
1	1	CH List	List
2	2	Smart Hub	Smart
3	3	Menu	Menu
4	4	Search	TV/R
5	5	Tools	Options
6	6	Info	Info
7	7	Return	Back
8	8	Exit	Exit
9	9	Up	Up
0	0	Down	Down
TTX/MIX	Text	Right	Right
PRE-CH	Pre Ch	Left	Left
Vol+	Vol +	Enter	Ok
Vol-	Vol -	Red	Red
Mute	Mute	Green	Green





	Original	Sustituto	Original	Sustituto
	Yellow			
	Blue			
	Social TV			
	HDMI			
	3D			
	E-Manual			
	P.Size			
	SRS			
	<<			
	I<<			
	Pause			
	>>			
	>>I			
	Rec			
	Play			
	Stop			

