



Original		Sustituto		Original		Sustituto	
	Power		Power		Vol+		Vol +
	Open/Close		Eject		Vol-		Vol -
	1		1		Mute		Mute
	2		2		Goto		Media
	3		3		PBC		Red
	4		4		Pause		Pause
	5		5		Play		Play
	6		6		Stop		Stop
	7		7		Setup		Options
	8		8		Return		Back
	9		9		Source		AV
	0		0		Tv/Radio		TV/R
	10+		Pre Ch		Up		Up
	Display		Info		Down		Down
	Title/TTX		Text		Right/FAV+		Right
	Menu		Menu		Left/FAV-		Left
	Prog/EPG		Guide		Enter		Ok





	Original	Sustituto	Original	Sustituto
REV	<<	<<		
FWD	>>	>>		
PREV	I<<	I<<		
NEXT	>>I	>>I		
3D	3D	3D		
SUBTITLE	Subtitle	Subt		
ZOOM	Zoom	SHIFT + ZOOM		Shift + Eject
MODE	Mode	E-MANUAL D.MENU		D. Menu
DIGEST	Digest	D		Blue
LANGUAGE	Language	SOUND DUAL		Dual
L/R	L/R	B		Green
P/N	P/N	C		Yellow
REPEAT	Repeat	SHIFT + REPEAT TEXT		Shift + Text
ANGLE	Angle	PICTURE FORMAT		Format
A-B	A-B	DISC NAV LIST		List
SLOW	Slow	HOME SMART		Smart

