



Original	Sustituto
Standby	Power
Info	Info / Angle
Subtitle	Subtitle / EQ
Mute	Mute / Dimmer
I<<	I<< / Preset-
Play	Play / Slow
<<	<< / Tune-
>>I	>>I / Preset+
Pause	Pause / Step / Freeze
>>	>> / Tune+
Menu	Menu / Home
Up	Up
CH+	CH+ / Page+
Exit	Exit / Cancel / Clear
Left	Left
Vol-	Vol-
OK	OK

Original	Sustituto
Right	Right
Vol+	Vol+
Record	Rec / Rec Mode
Down	Down
CH-	CH- / Page-
Stop	Stop / Hold
1	1
2	2
3	3
EPG	Guide / EPG / -/-
4	4
5	5
6	6
Back	Back / Return
7	7
8	8
9	9



