





































Original	Sustituto
 Continue	 Options
 Shuffle	 TV/R
 Program	 Sleep
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 10	 0
 >10	 Guide
 Clear	 Exit
 Time	 AV
 Check	 Media

Original	Sustituto
 Repeat	 Text
 Fader	 Mute
 Play	 Play
 Pause	 Pause
 Stop	 Stop
 I<< AMS	 I<<
 AMS >>I	 >>I
 <<	 <<
 >>	 >>

