






































































Original	Sustituto	Original	Sustituto
 Power	 Power	 TV/Radio	 TV/R
 Social View	 Media	 [≡]	 Text
 Input	 AV	 Red	 Red
 Digital/Analog	 Eject	 Green	 Green
 Exit	 Exit	 Yellow	 Yellow
 Football	 List	 Blue	 Blue
 3D	 3D	 X/Related Search/Track ID	 Shift + TV/R
 1	 1	 Sync Menu	 Menu
 2	 2	 ?/i-Manual	 D. Menu
 3	 3	 Discover	 Sleep
 4	 4	 [i+]/[?]	 Info
 5	 5	 Return/Back	 Back
 6	 6	 Options	 Options
 7	 7	 Home	 Smart
 8	 8	 Guide	 Guide
 9	 9	 Up	 Up
 0	 0	 Down	 Down





Original	Sustituto	Original	Sustituto

