



Original	Sustituto
Power	Power
Input	AV
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
-/	Guide
Pre CH	Pre Ch
<<	<<
Stop	Stop
Play	Play

Original	Sustituto
>>	>>
V.Menu	D. Menu
Mute	Mute
P+	Ch +
P-	Ch -
Up	Up
Down	Down
Right	Right
Left	Left
Vol+	Vol +
Vol-	Vol -
Menu	Menu
Display	Info
P.STD	3D
Rec	Rec
Eject	Eject
Pause/P/S&LNA	Pause





Original	Sustituto	Original	Sustituto
Crystal PB	TV/R		
TRK up	>>I		
TRK Down	I<<		
Index	List		
Memory	Ok		
Sleep	Sleep		
Lang.Sel	Dual		
Clear	Exit		

