







































































Original	Sustituto
 Power	 Power
 FAV	 Pre Ch
 TV / RAD	 TV/R
 SUB	 Subt
 Mute	 Mute
 Up / Channel +	 Up
 Up / Channel +	 Ch +
 Down / Channel -	 Down
 Down / Channel -	 Ch -
 Right / Vol +	 Right
 Right / Vol +	 Vol +
 Left / Vol -	 Left
 Left / Vol -	 Vol -
 OK / Play	 Ok
 OK / Play	 Play
 Text	 Text
 Sat / Stop	 Media

Original	Sustituto
 Sat / Stop	 Stop
 Back	 Back
 Menu	 Menu
 i / Rec	 Info
 i / Rec	 Rec
 EPG	 Guide
 Page + / >>	 >>
 Page - / <<	 <<
 AV	 AV
 Audio	 Dual
 Pause	 Pause
 Red / Contrast -	 Red
 Green / Contrast	 Green
 Yellow / Brightness -	 Yellow
 Blue / Brightness	 Blue
 1	 1
 2	 2



