

















































































Original	Sustituto	Original	Sustituto
 Power	 Power	 1	 1
 Tv System	 TV/Radio /	 2	 2
 Mute	 Mute / Dimmer	 3	 3
 Rec	 Rec / Rec Mode	 4	 4
 Browser	 Smart / List	 5	 5
 Timer	 Sleep / Timer	 6	 6
 Copy	 D.Menu / Top	 7	 7
 Guide	 Guide / EPG / -/-	 8	 8
 Vol-	 Vol-	 9	 9
 Up	 Up	 0	 0
 Vol+	 Vol+	 Goto	 Text / Goto
 Left	 Left	 Slow	 Shift + Play /
 Enter	 Shift + OK	 Option	 Shift + Setup / OPT / Tools
 Right	 Right	 Play	 Play / Slow
 Return	 Back / Return	 Stop	 Stop / Hold
 Down	 Down	 Pause/Step	 Pause / Step / Freeze
 Setup	 Setup / OPT /	 I<</Prev	 I<< / Preset-



Tools



	Original	Sustituto	Original	Sustituto
	 NEXT >> /Next	 PRESET+ >> / Preset+		
	 FR <</FR	 TUNE- << / Tune-		
	 FF >>/FF	 TUNE+ >> / Tune+		
	 SUBTITLE Subtitle	 EQ Subtitle / EQ		
	 DISPLAY Display	 MEDIA DISPLAY Display / Media		
	 AUDIO Audio	 LANG I/II Audio / Lang I/II		
	 ZOOM Zoom	 SIZE ZOOM Zoom / Size		
	 TIME SHIFT Time Shift	 SHIFT + SLEEP Shift + Sleep / Timer		
	 REPEAT Repeat	 APP REPEAT Green / APP / Repeat		
	 SELECT Select	 OK OK		
	 CONFIRM Confirm	 SHIFT + LIST SMART Shift + Smart / List		

