





































Original	Sustituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 [=?] / Source	 AV
 [=i] / Info	 Info
 DMP	 Smart
 EPG	 Guide
 Up	 Up

Original	Sustituto
 Left	 Left
 Enter	 Ok
 Right	 Right
 Down	 Down
 Menu	 Menu
 Exit	 Exit
 Vol+	 Vol +
 Vol-	 Vol -
 List	 List
 CH+	 Ch +
 CH-	 Ch -
 FAV	 Pre Ch
 Sleep	 Sleep
 Index	 Shift + Info
 Red / <<	 Red
 Red / <<	 <<
 Green / >>	 Green







































Original	Sustituto	Original	Sustituto
 Green / >>>	 >>>		
 Yellow / I<<<	 Yellow		
 Yellow / I<<<	 I<<<		
 Blue / >>>I	 Blue		
 Blue / >>>I	 >>>I		
 [=] / Play/Pause	 Text		
 [=] / Play/Pause	 Play		
 [=] / Play/Pause	 Pause		
 [=□] / Stop/Still	 Stop		
 [=⊙] / Subtitle	 Subt		
 [=⇕] 3D	 3D		
 [=X]	 Shift + Exit		
 Recall	 Back		
 Radio	 TV/R		
 Audio / I/II	 Dual		
 Rec	 Rec		





Original	Sustituto	
Power		Power
Mute		Mute
1		1
2		2
3		3
4		4
5		5
6		6
7		7
8		8
9		9
0		0
[≡?]/Source		AV
[≡i]/Info		Info
DMP		Smart
EPG		Guide
Menu		Menu

Original	Sustituto	
Exit		Exit
Up		Up
Down		Down
Right		Right
Left		Left
Enter		Ok
Vol+		Vol +
Vol-		Vol -
List		List
CH+		Ch +
CH-		Ch -
♥		Pre Ch
Sleep		Sleep
Index		Shift + Info
Back		Back
Red		Red
Green		Green





Original	Sustituto	Original	Sustituto
Yellow	 C	Yellow	
Blue	 D	Blue	
<<		<<	
>>		>>	
I<<		I<<	
>>I		>>I	
Play	 PLAY MODE	Play	
Pause		Pause	
Stop/Still		Stop	
[≡+]	 PICTURE FORMAT	Format	
[≡]	 REPEAT TEXT	Text	
[≡o]/Subtitle	 AD SUBT	Subt	
[≡♦]/[+]	 ECO 3D	3D	
[≡x]	 SETTINGS OPT	Options	
Radio	 SEARCH TV/R	TV/R	
Audio	 SOUND DUAL	Dual	
Rec	 REC MODE	Rec	

