








































































| Original | Sustituto | Original | Sustituto |
|-------------|--|------------|---|
| On/Off |  Power | OK Enter |  Ok |
| Mute |  Mute | Menu Right |  Right |
| Update |  Play | Menu Off |  Exit |
| Reveal |  Pause | Menu Down |  Down |
| Txt Stop |  Stop | Back |  Back |
| Info |  +  Shift + Info | Volume+ |  Vol + |
| Subt.List |  Subt | Chan.Up |  Ch + |
| Sleep Timer |  Sleep | Volume- |  Vol - |
| Return TV |  TV/R | Menu audio |  Dual |
| Menu video |  D. Menu | Chan.Down |  Ch - |
| Text |  Text | 1 |  1 |
| Txt Expand |  Eject | 2 |  2 |
| TV/AV |  AV | 3 |  3 |
| Menu |  Menu | 4 |  4 |
| Menu Up |  Up | 5 |  5 |
| Display |  Info | 6 |  6 |
| Menu Left |  Left | 7 |  7 |



| Original | Sustituto | Original | Sustituto |
|----------------|---|----------------|-----------|
| 8 |  | 8 | |
| 9 |  | 9 | |
| Guide -/-- 1. |  | Guide | |
| 0/10 |  | 0 | |
| 2.Fav P/C 2. |  | Pre Ch | |
| Red |  | Red | |
| Green |  | Green | |
| Yellow |  | Yellow | |
| Blue |  | Blue | |
| Audio- |  +  | Shift + Play | |
| Audio+ |  +  | Shift + Pause | |
| Tone- |  | I<< | |
| Tone+ |  +  | Shift + >>I | |
| On/Tim |  +  | Shift + Subt | |
| Off/Tim |  +  | Shift + Sleep | |
| Disp |  | List | |
| Color+ P.Std |  | >> | |
| Mix Scan |  +  | Shift + TV/R | |
| Tune- |  +  | Shift + Left | |
| Aft/Caf |  +  | Shift + Ok | |
| Tune+ |  +  | Shift + Right | |
| Bright- Sys |  +  | Shift + Exit | |
| Contrast+ |  +  | Shift + Ch + | |
| Color- S.Std |  | << | |
| Contrast- |  +  | Shift + Ch - | |
| 3.* |  +  | Shift + Guide | |
| 4.# 16:9 |  | Format | |
| Surround |  +  | Shift + Red | |
| Nicam/Mono |  +  | Shift + Green | |
| Level L |  +  | Shift + Yellow | |
| Level R/Woofer |  +  | Shift + Blue | |



| Original | Sustituto | Original | Sustituto |
|-------------|--|---------------|---|
| On/Off |  Power | Menu Down |  Down |
| Mute |  Mute | Back |  Back |
| Reveal |  Pause | Volume+ |  Vol + |
| Txt Stop |  Stop | Chan.Up |  Ch + |
| Info |  +  Shift + Info | Volume- |  Vol - |
| Subt.List |  Subt | Menu audio |  Dual |
| Sleep Timer |  Sleep | Chan.Down |  Ch - |
| Return TV |  TV/R | 1 |  1 |
| Menu video |  D. Menu | 2 |  2 |
| Text |  Text | 3 |  3 |
| Txt Expand |  Eject | 4 |  4 |
| Menu |  Menu | 5 |  5 |
| Menu Up |  Up | 6 |  6 |
| Display |  Info | 7 |  7 |
| Menu Left |  Left | 8 |  8 |
| OK Enter |  Ok | 9 |  9 |
| Menu Right |  Right | Guide -/-- 1. |  Guide |



| Original | Sustituto | Original | Sustituto |
|--------------|--|----------|-----------|
| 0/10 |  0 | | |
| 2.Fav P/C 2. |  Pre Ch | | |
| Red |  Red | | |
| Green |  Green | | |
| Yellow |  Yellow | | |
| Blue |  Blue | | |
| Tone+ |  Smart | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

