







Original	Sustituto
	Power
	Mute / Dimmer
	Red / Netflix / Search
	Red / Media
	Green / APP / Repeat
	Green / TV
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Blue / APP
	Vol-
	I<< / Preset-
	>>I / Preset+
	Vol+
	D.Menu / Top
	CH+ / Page+
	Up
	Back / Return

Original	Sustituto
	Left
	OK
	Right
	Menu / Home
	CH- / Page-
	Down
	Info / Angle
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Guide / EPG / -/-





Original	Sustituto	Original	Sustituto
	0		0
	<x]		Fav / Marker / PC









Original	Sustituto
	Power
	Mute / Dimmer
	Red / Netflix / Search
	Red / Media
	Green / APP / Repeat
	Green / TV
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Blue / APP
	Vol-
	I<< / Preset-
	>>I / Preset+
	Vol+
	D.Menu / Top
	Up
	CH+ / Page+
	Back / Return

Original	Sustituto
	Left
	OK
	Right
	Menu / Home
	Down
	CH- / Page-
	Info / Angle
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Guide / EPG / -/-





	Original	Sustituto	Original	Sustituto
	0	 0		
	<x]	 Fav / Marker / PC		

