



Original	Sustituto	Original	Sustituto
Standby	Power	Down	Down
Info	Info	Right	Right
Subtitle	Subt	Left	Left
Mute	Mute	OK	Ok
I<<	I<<	Vol+	Vol +
>>I	>>I	Vol-	Vol -
Play	Play	1	1
Pause	Pause	2	2
<<	<<	3	3
>>	>>	4	4
Record	Rec	5	5
Stop	Stop	6	6
Menu	Menu	7	7
Exit	Exit	8	8
CH+	Ch +	9	9
CH-	Ch -	0	0
Up	Up	EPG	Guide





Original	Sustituto	Original	Sustituto
	Back		Back
	Media		Media
	USB		Smart
	Tv/Radio		TV/R
	Audio		Dual
	TTX		Text
	Timer		AV
	FAV		Pre Ch
	Res		Options
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue

Original	Sustituto

