



Original	Sustituto	Original	Sustituto
ON / STANDBY	Power		
INPUT	AV / Input / RDS		
Set Up	Setup / OPT /		
MENU	Menu / Home		
MUTE	Mute / Dimmer		
Freeze	Pause / Step / Freeze		
UP	Up		
LEFT	Left		
ENTER	OK		
RIGHT	Right		
DOWN	Down		
RETURN	Back / Return		

Original	Sustituto

