




Original	Sustituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 FAV	 Pre Ch
 Recall	 Back
 Lang	 Dual
 Time Shift	 Smart
 Tv/Radio	 TV/R

Original	Sustituto
 Dev.List	 List
 EPG	 Guide
 Subtitle	 Subt
 Text	 Text
 Auto	 Options
 Menu	 Menu
 Zoom	 Eject
 Info	 Info
 Exit	 Exit
 CH+	 Ch +
 CH-	 Ch -
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 Vol+	 Vol +





Original	Sustituto	Original	Sustituto
 Vol-	 Vol -		
 Filelist	 Media		
 Rec	 Rec		
 Stop	 Stop		
 Play	 Play		
 Pause	 Pause		
 <<	 <<		
 >>	 >>		
 I<<	 I<<		
 >>I	 >>I		
 Red/FAV/Daily	 Red		
 Green/DEL/Weekl	 Green		
 Yellow/Movie/P.Inf	 Yellow		
 Blue/Lock/Timer	 Blue		

