



Original	Sustituto
 Power Receiver	 Power
 Power Source	 Shift + Power
 HDMI 1	 Shift + 1
 HDMI 2	 Shift + 2
 HDMI 3	 Shift + 3
 HDMI 4	 Shift + 4
 HDMI 5	 Shift + 5
 V-AUX	 Shift + TV/R
 AV 1	 Shift + 6
 AV 2	 Shift + 7
 AV 3	 Shift + 8
 AV 4	 Shift + 9
 AV 5	 Shift + Guide
 AV 6	 Shift + 0
 Audio 1	 Shift + Pre Ch
 Audio 2	 Format
 Tuner	 TV/R

Original	Sustituto
 USB	 Media
 Net	 Shift + Options
 *	 Exit
 BD/DVD	 Red
 TV	 Green
 NET	 Yellow
 Radio	 Blue
 Program Up	 Ch +
 Program Down	 Ch -
 Volume+	 Vol +
 Volume-	 Vol -
 Mute	 Mute
 Top Menu	 Menu
 Pop-Up/Menu	 D. Menu
 On Screen	 3D
 Option	 Options
 Return	 Back





Original	Sustituto
 Display	 Shift + Info
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 Mode	 Eject
 Stop	 Stop
 Pause	 Pause
 Play/Band	 Play
 Preset >>I	 >>I
 I<< Preset	 I<<
 Tuning >>	 >>
 << Tuning	 <<
 Movie	 Smart
 Music	 List
 Sur.Decode	 Dual

Original	Sustituto
 Straight	 AV
 Info	 Info
 Sleep	 Sleep
 Enhancer	 Subt
 Pure Direct	 Text
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 +10/Memory	 Guide
 ENT	 Pre Ch





Original	Sustituto
 Power Receiver	 Power
 Power Source	 +  Shift + Power
 HDMI 1	 +  Shift + 1
 HDMI 2	 +  Shift + 2
 HDMI 3	 +  Shift + 3
 HDMI 4	 +  Shift + 4
 HDMI 5	 +  Shift + 5
 V-AUX	 +  Shift + TV/R
 AV 1	 +  Shift + 6
 AV 2	 +  Shift + 7
 AV 3	 +  Shift + 8
 AV 4	 +  Shift + 9
 AV 5	 +  Shift + Guide
 AV 6	 +  Shift + 0
 Audio 1	 +  Shift + Pre Ch
 Audio 2	 Format
 Tuner	 TV/R

Original	Sustituto
 USB	 Media
 Net	 +  Shift + Options
 *	 Exit
 BD/DVD	 Red
 TV	 Green
 NET	 Yellow
 Radio	 Blue
 Volume+	 Vol +
 Volume-	 Vol -
 Mute	 Mute
 Top Menu	 Menu
 Pop-Up/Menu	 D. Menu
 On Screen	 3D
 Option	 Options
 Return	 Back
 Display	 +  Shift + Info
 Up	 Up



