




Original	Sustituto
 Power	 Power
 Display	 Info
 Mute	 Mute
 TV	 TV/R
 AV	 AV
 Scart	 Smart
 PC	 Media
 Sleep	 Sleep
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9

Original	Sustituto
 0	 0
 Recall	 Pre Ch
 Enter	 Guide
 Menu	 Menu
 TTX/MIX	 Text
 Wide	 3D
 MPX	 Options
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 CH+	 Ch +
 CH-	 Ch -
 Red	 Red





Original		Sustituto		Original		Sustituto	
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Subtitle		Subt				
	Index		List				
	Subpage		D. Menu				
	Reveal		Dual				
	Size		Format				
	Hold		Eject				

