
























































































































































Original	Sustituto	Original	Sustituto
 Power	 Power	 Exit/Back	 Exit
 Mute	 Mute	 Up	 Up
 1	 1	 Left	 Left
 2	 2	 OK	 Ok
 3	 3	 Right	 Right
 4	 4	 Down	 Down
 5	 5	 P+	 Ch +
 6	 6	 P-	 Ch -
 7	 7	 Vol+	 Vol +
 8	 8	 Vol-	 Vol -
 9	 9	 [◀▶]	 Format
 0	 0	 → ◻ ←	 TV/R
 Recall	 FAV PRE-CH	 [i+] / [≡i]	 DISPLAY INFO
 Source	 TIMER AV	 Text / [≡] / [≡] []	 REPEAT TEXT
 Menu/DVD	 TOP MENU MENU	 [] / [▶]	 [] Pause
 Guide	 -/-- GUIDE	 [▶] / [I/I]	 [▶] PLAY MODE
 [■][■][■]	 ECO 3D	 [▶] / [I/I]	 [▶] SOUND DUAL

































































Original	Sustituto	Original	Sustituto
 Power	 Power	 Right	 Right
 Mute	 Mute	 Down	 Down
 1	 1	 Vol+	 Vol +
 2	 2	 Vol-	 Vol -
 3	 3	  / [v]	 Pause
 4	 4	  / I/II	 Play
 5	 5	  / I/II	 Dual
 6	 6	  / [≡●]	 <<<
 7	 7	  / [≡●]	 TV/R
 8	 8	  / Subtitle	 >>>
 9	 9	  / Subtitle	 Subt
 0	 0	  ▲	 Smart
 _ Menu/DVD	 Menu	  / [≡□]	 Stop
 - Exit/Back	 Exit	  / [≡⇅]	 Eject
 - Up	 Up	  / [≡⇅]	 I<<<
 Left	 Left	  / [⊙][≡X]	 >>>I
 OK	 Ok	  / [⊙][≡X]	 Back





Original	Sustituto	Original	Sustituto
 Power	 Power	 Mute	 Mute
 1	 1	 2	 2
 3	 3	 4	 4
 5	 5	 6	 6
 7	 7	 8	 8
 9	 9	 0	 0
 Source	 AV	 P+	 Ch +
 P-	 Ch -	 Vol-	 Vol -
 Vol+	 Vol +		

Original	Sustituto	Original	Sustituto
 Pause	 Pause	 Play	 Play
 Fast Forward	 Dual	 Fast Reverse	 <<<
 Stop	 TV/R	 Subtitle	 >>>
 Subtitle	 Subt	 Home	 Smart
 Stop	 Smart	 Eject	 Eject
 Eject	 Eject	 Back	 Back
 [X]	 Back	 [X]	 >>>

