




































































Original	Sustituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Info	 Info
 AV	 AV
 Red	 Red
 Green	 Green
 Yellow	 Yellow

Original	Sustituto
 Blue	 Blue
 TV/DTV	 TV/R
 Menu	 Menu
 Top Menu/[≡]	 Shift + Menu
 Back	 Back
 PR+	 Ch +
 PR-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 <</F.T/L	 <<
 Play/?/TV/Radio	 Play
 >>/[-]/Guide	 >>







































Original	Sustituto	Original	Sustituto
 Rec/>	 Rec		
 Stop/[X]/I-II	 Stop		
 Pause/[i+]/[...]	 Pause		
 ^/[--]	 Subt		
 v/[]	 Format		
 Zoom	 Eject		
 (↔)	 Options		
 [*]/Music	 Dual		
 [: :]	 3D		





	Original	Sustituto	Original	Sustituto
	Power			
	(i)			
	Menu			
	Up			
	Down			
	Right			
	Left			
	OK			
	Top Menu	 +  Shift + Menu		
	Back			
	↑/[+]	 Pre Ch		
	↓/[]	 Guide		
	<<	 <<		
	Play	 Play		
	>>	 >>		
	Stop	 Stop		
	Pause	 Pause		





Original	Sustituto
Power	Power
(i)	Info
Green	Green
Yellow	Yellow
Blue	Blue
Menu	Menu
Up	Up
Down	Down
Right	Right
Left	Left
OK	Ok
Top Menu	Shift + Menu
Back	Back
↓/[I]	Guide
↑/[+]	Pre Ch
<<	<<
Play	Play

Original	Sustituto
>>	>>
Rec	Rec
Stop	Stop
Pause	Pause





Original	Sustituto
Power	Power
Mute	Mute
(i)	Info
Menu	Menu
Up	Up
Down	Down
Right	Right
Left	Left
OK	Ok
Top Menu	+ Shift + Menu
Back	Back
↑/[+]	Pre Ch
↓/[]	Guide
<<	<<
Play	Play
>>	>>
Pause	Pause

Original	Sustituto
Stop	Stop
(↔)	Media

