











Original	Sustituto
Standby	Power
Mute	Mute
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
F.List	Media
RES	Smart
Repeat	Text
Capture	Format
Book.M	3D

Original	Sustituto
Book.J	Shift + 3D
R.Skip	I<<
REW	<< button"/> <<
FWD	>>
F.Skip	>>I
Rec	Rec
Stop	Stop
Play	Play
Pause	Pause
Menu	Menu
Exit	Exit
Info	Info
Back	Back
Up	Up
Left	Left
OK	Ok
Right	Right





Original	Sustituto
	 Down
	 Vol +
	 Vol -
	 Ch +
	 Ch -
	 Red
	 Dual
	 Green
	 Subt
	 Yellow
	 Shift + Text
	 Blue
	 Sleep
	 Guide
	 Pre Ch
	 List
	 Eject

Original	Sustituto
	 Options
	 Shift + Options
	 TV/R
	 AV

