







































































| Original   | Sustituto   | Original   | Sustituto  |
|--|---|--|--|
|  On             |  Power         |  Left           |  Left     |
|  Off            |  Shift + Power |  1              |  1        |
|  Vol+           |  Vol +         |  2              |  2        |
|  Vol-           |  Vol -         |  3              |  3        |
|  Mute           |  Mute          |  4              |  4        |
|  Test           |  Smart         |  5              |  5        |
|  Night          |  Exit          |  6              |  6        |
|  [=]            |  Text          |  7              |  7        |
|  Sleep          |  Sleep         |  8              |  8        |
|  Surr.          |  Dual          |  9              |  9        |
|  SPKR/Menu      |  Menu          |  0              |  0        |
|  Delay/Normal |  Info        |  Tun-M/[≡+]   |  Guide  |
|  CH./[≡?]     |  TV/R        |  Mem/[≡◇]     |  Pre Ch |
|  Digital/[≡X] |  Media       |  Tuning ▲     |  Ch +   |
|  Up           |  Up          |  Tuning ▼     |  Ch -   |
|  Down         |  Down        |  Direct/Green |  Green  |
|  Right        |  Right       |  Clear/Yellow |  Yellow |









































































| Original     | Sustituto    |
|--------------|--------------|
| Preset ▲     | Shift + Ch + |
| Preset ▼     | Shift + Ch - |
| RDS/D.Skip   | Options      |
| Set          | Ok           |
| Red          | Red          |
| Blue         | Blue         |
| DVD          | Shift + 2    |
| AVR          | Shift + 1    |
| CD           | Shift + 3    |
| Tape         | Shift + 4    |
| VID1/VCR     | Shift + 5    |
| VID2/TV      | Shift + 6    |
| VID3/CBL/SAT | Shift + 7    |
| VID4         | Shift + 8    |
| AM/FM        | Shift + 9    |
| > DVD        | Play         |
| << DVD       | <<           |

| Original      | Sustituto |
|---------------|-----------|
| >> DVD        | >>        |
| Stop DVD      | Stop      |
| Pause DVD     | Pause     |
| I<</Skip Down | I<<       |
| Skip Up/>>I   | >>I       |





| Original   | Sustituto   | Original   | Sustituto  |
|--|---|--|--|
|  Power On     |  Power         |  3            |  3              |
|  Power Off    |  Shift + Power |  4            |  4              |
|  Night        |  Exit          |  5            |  5              |
|  [=]          |  Text          |  6            |  6              |
|  Vol+         |  Vol +         |  7            |  7              |
|  Vol-         |  Vol -         |  8            |  8              |
|  SPKR/Menu    |  Menu          |  9            |  9              |
|  CH./[≡?]     |  TV/R          |  0            |  0              |
|  Digital/[≡X] |  Media         |  Tun-M/[≡+]   |  Guide          |
|  Delay/Normal |  Info          |  Mem/[≡◇]     |  Pre Ch         |
|  Up         |  Up          |  Direct     |  Smart        |
|  Down       |  Down        |  Clear      |  Shift + Exit |
|  Right      |  Right       |  Preset ▲   |  Ch +         |
|  Left       |  Left        |  Preset ▼   |  Ch -         |
|  Set        |  Ok          |  RDS/D.Skip |  Options      |
|  1          |  1           |  >>         |  >>           |
|  2          |  2           |  <<         |  <<           |









































































|  | Original | Sustituto |  | Original | Sustituto |
|--|----------|-----------|--|----------|-----------|
|  | Play     | Play      |  |          |           |
|  | Stop     | Stop      |  |          |           |
|  | Pause    | Pause     |  |          |           |
|  | >>I      | >>I       |  |          |           |
|  | I<<      | I<<       |  |          |           |
|  |          |           |  |          |           |
|  |          |           |  |          |           |
|  |          |           |  |          |           |
|  |          |           |  |          |           |
|  |          |           |  |          |           |
|  |          |           |  |          |           |
|  |          |           |  |          |           |
|  |          |           |  |          |           |
|  |          |           |  |          |           |
|  |          |           |  |          |           |
|  |          |           |  |          |           |
|  |          |           |  |          |           |
|  |          |           |  |          |           |
|  |          |           |  |          |           |
|  |          |           |  |          |           |
|  |          |           |  |          |           |
|  |          |           |  |          |           |
|  |          |           |  |          |           |
|  |          |           |  |          |           |
|  |          |           |  |          |           |





| Original  |              | Sustituto   |               | Original  |                 | Sustituto   |              |
|---|--------------|---|---------------|---|-----------------|---|--------------|
|    | Power On     |    | Power         |    | Preset ▲/Blue   |    | Ch +         |
|    | Power Off    |    | Shift + Power |    | RDS/D.Skip      |    | Options      |
|    | SPKR/Menu    |    | Menu          |    | >>              |    | >>           |
|    | Delay/Normal |    | Info          |    | <<              |    | <<           |
|    | 1            |    | 1             |    | Play            |    | Play         |
|    | 2            |    | 2             |    | Stop            |    | Stop         |
|    | 3            |    | 3             |    | Pause           |    | Pause        |
|    | 4            |    | 4             |    | >>              |    | >>           |
|    | 5            |    | 5             |    | <<              |    | <<           |
|    | 6            |    | 6             |    | Power (On /Off) |    | Media        |
|  | 7            |  | 7             |  | PR+ VCR         |  | Shift + Ch + |
|  | 8            |  | 8             |  | PR- VCR         |  | Ch -         |
|  | 9            |  | 9             |  | Vol+ VCR        |  | Vol +        |
|  | 0            |  | 0             |  | Vol- VCR        |  | Vol -        |
|  | Tun-M/[≡+]   |  | Guide         |  | Input VCR       |  | AV           |
|  | Mem/[≡◆]     |  | Pre Ch        |  | 1 VCR           |  | Shift + 1    |
|  | Direct       |  | Smart         |  | 2 VCR           |  | Shift + 2    |















| Original  | Sustituto    |
|-----------|--------------|
| 3 VCR     | +  Shift + 3 |
| 4 VCR     | +  Shift + 4 |
| 5 VCR     | +  Shift + 5 |
| 6 VCR     | +  Shift + 6 |
| 7 VCR     | +  Shift + 7 |
| 8 VCR     | +  Shift + 8 |
| 9 VCR     | +  Shift + 9 |
| 0 VCR     | +  Shift + 0 |
| Clear VCR | Exit         |
| Play VCR  | Red          |
| Stop VCR  | Green        |
| Rec VCR   | Rec          |
| >> VCR    | Blue         |
| << VCR    | Yellow       |
|           |              |
|           |              |
|           |              |

| Original | Sustituto |
|----------|-----------|
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |





| Original  | Sustituto | Original  | Sustituto |
|---|-----------|---|-----------|
|  | <>        |  | Play      |
|  | >>        |  | >>        |
|  | <<        |  | <<        |
|  | Stop      |  | Stop      |
|  | Rec       |  | Rec       |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |

