







































































| Original  | Sustituto      | Original  | Sustituto |
|---|----------------|---|-----------|
|      | Power          |      | Power     |
|      | Mute           |      | Mute      |
|      | Function       |      | Smart     |
|      | Input          |      | AV        |
|      | Sleep          |      | Sleep     |
|      | Return         |      | Back      |
|      | EQ             |      | Red       |
|      | VSM            |      | Green     |
|      | 1              |      | 1         |
|      | 2              |      | 2         |
|     | 3              |     | 3         |
|    | 4              |    | 4         |
|    | 5              |    | 5         |
|    | 6              |    | 6         |
|    | 7              |    | 7         |
|    | 8              |    | 8         |
|    | 9              |    | 9         |
|    | 0              |    | 0         |
|    | Setup          |    | Options   |
|    | Display        |    | Info      |
|    | Up / Preset+   |    | Up        |
|    | Down / Preset- |    | Down      |
|    | Right / Tun+   |    | Right     |
|    | Left / Tun-    |    | Left      |
|    | Enter          |    | Ok        |
|    | Menu           |    | Menu      |
|    | Title          |    | 3D        |
|   | << / Scan-     |   | <<        |
|  | >> / Scan+     |  | >>        |
|  | Play           |  | Play      |
|  | I<< / Skip-    |  | I<<       |
|  | >>I / Skip+    |  | >>I       |
|  | Pause / Step   |  | Pause     |
|  | Prog. Memo.    |  | TV/R      |





| Original | Sustituto     |
|----------|---------------|
|          | Rec           |
|          | Stop          |
|          | Vol +         |
|          | Vol -         |
|          | Text          |
|          | Subt          |
|          | Yellow        |
|          | Blue          |
|          | Dual          |
|          | Exit          |
|          | Shift + Power |
|          | Shift + AV    |
|          | Shift + Ch +  |
|          | Shift + Ch -  |
|          | Shift + Vol + |
|          | Shift + Vol - |

| Original | Sustituto |
|----------|-----------|
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |

