



Original	Sustituto
	 Power
	 Info / Angle
	 Menu / Home
	 D.Menu / Top
	 1
	 2
	 3
	 AV / Input / RDS
	 4
	 5
	 6
	 Smart / List
	 7
	 8
	 9
	 Guide / EPG / -/-
	 Sleep / Timer

Original	Sustituto
	 0
	 Mute / Dimmer
	 Exit / Cancel / Clear
	 Vol+
	 Up
	 CH+ / Page+
	 Left
	 OK
	 Right
	 Vol-
	 Down
	 CH- / Page-
	 TV/Radio /
	 Text / Goto
	 Fav / Marker / PC
	 Picture / Format
	 Subtitle / EQ



