



























































Original	Sustituto
 Power	 Power
 Mute	 Mute / Dimmer
 Red	 Red / Netflix / Search
 <<	 << / Tune-
 Green	 Green / APP / Repeat
 >>	 >> / Tune+
 Yellow	 Yellow / YouTube / Repeat
 I<<	 I<< / Preset-
 Blue	 Blue / Prime Video / Random
 >>I	 >>I / Preset+
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 Stop	 Stop / Hold
 Index	 Info / Angle
 Size	 Zoom / Size
 Hold	 Shift + Stop /
 Subtitle	 Subtitle / EQ

Original	Sustituto
 Mix	 Picture / Format
 Reveal	 D.Menu / Top
 TTX	 Text / Goto
 Clock	 Sleep / Timer
 Audio Language	 Audio / Lang I/II
 Rec	 Rec / Rec Mode
 S	 Sound / Title
 R	 Display / Media
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 M	 Menu / Home
 Exit	 Exit / Cancel / Clear
 Vol+	 Vol+
 Flip	 Smart / List





Original	Sustituto	Original	Sustituto
CH+	CH+ / Page+		
Vol-	Vol-		
EPG	Guide / EPG / -/--		
CH-	CH- / Page-		
1	1		
2	2		
3	3		
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
FAV	Fav / Marker / PC		
0	0		
Recall	Back / Return		

Original	Sustituto	Original	Sustituto

